

	SILNIK
TOYOTA	4FG-18
TOYOTA	4FG-20; 4FGC-20
TOYOTA	4FG-23; 4FGC-23
TOYOTA	4FG-25; 4FGC-25
TOYOTA	4FGL10
TOYOTA	4FGL14
TOYOTA	4FGL15
TOYOTA	4FGL18
TOYOTA	4FGL20
TOYOTA	4FGL23

TOYOTA: 28100-14014 28100-23010 28100-23011 28100-31020 28100-31021 28100-31022 28100-31030 28100-40010 28100-40011 28100-40012 28100-40013 28100-40014 28100-40015 28100-40100 28100-40110 28100-40120 28100-40130 28100-40140

NIPPONDENSO: 028000-0197 028000-1010 028000-1011 028000-1012 028000-1013 028000-1016 028000-1080 028000-1081 028000-1082 028000-1083 028000-1970 028000-1971 028000-1972 028000-1973 028000-1974 028000-1975 028000-1976 028000-3770 028000-4810 028000-4811 028000-4812 028000-6820 028000-6821 028000-6822 028000-6823 028000-7520 028000-7521 028000-9010


